


TRI-MODE CONNECTION (fig. 1)



FREQUENCY Hertz	LOUDSPEAKERS IMPEDANCE					
	4 Ohms			8 Ohms		
	L mH	C µF		L mH	C µF	
60	10.6	660		21.0	330	
80	7.9	495		15.9	245	
100	6.4	400		12.7	200	
120	5.3	330		10.6	165	
150	4.3	265		8.5	132	
200	3.2	200		6.4	100	

**OWNER'S MANUAL**

*Car power amplifier*

# HV sedici

PRINTED IN ITALY - Code 10124600-A

## **INTRODUCTION**

The **HV sedici** amplifier is the first born in a new family of high performance car amplifiers and other devices called **THESIS**.

It is endowed with highly innovative technologies and circuit solutions and its realization required big efforts and investments for research and development.

The purpose was to realize an amplifier that had to be a "milestone" in the evolutive history of **AUDISON** products.

Its structure in the circuit layout can be identified at two levels: the first one (power) is entirely on the mother circuit board and it collects all components which handle high currents and need warmth dissipation; the second one (signal and control) is located on special surface mounting devices which perform all complex functions of the whole device.

This peculiar design technique allowed the study and optimization of the signal paths and the blocking of the interactions among the different stages.

The **HV sedici** amplifier is constituted by three main parts: preamplifier, final power stage and power supply.

## **PREAMPLIFIER**

**HV sedici** amplifier is supplied with an independent preamplifier unit, where the general sensitivity can be adjusted in the 0.2÷1 V range.

This unit can be deactivated, allowing the connection with an external preamplifier.

The input signal is applied to ABS (Audison Balanced System) connector in balanced or unbalanced way, and to MA-1X module through two polypropylene capacitors.

MA-1X circuit, which constitutes the input interface for audio signals, is characterized by a FET-BJT hybrid circuitry in CASCODE configuration and it has been superintegrated in a single chip whose features are: max power supply:  $\pm 50$  VDC, S/N ratio: 125 dBA, Slew Rate: 120 V/ $\mu$ S, Bandwidth: DC÷1MHz.

## **FINAL POWER STAGE**

Balanced or unbalanced audio signal (it can be selected) applied to the input can directly drive the final stage without the preamplifier interposition.

By deactivating, the preamplifier, the final stage sensitivity can be between 1.0 ÷ 5 V.

The signal coming from the MA-1X module arrives in balanced connection to the V-AMP 12 LV module which makes the driving of the final stages in voltage and the thermic stability control.

The internal circuit is characterized by a double complementary differential amplifier in CASCODE connection with FET-BJT and current mirror combination. This circuit is integrated in two custom chips (CDAP - CDAN) whose components undergo a laser trim for the maximum tolerances reduction.

## **REGULATIONS**

All controls are located on top of the device.

- MONO ON-OFF: see MONO connection.

- BALANCED-UNBALANCED: see balanced-unbalanced connection.

- PREAMP ON-OFF: see connection to external preamplifier.

- L-R LEVELS: amplifier sensitivity adjustment, separated for the two channels.

## **PROCEED AS FOLLOWS**

Adjust the device according to the head unit requirements, through the above mentioned controls and regulations.

1) Set the two L-R LEVELS potentiometers towards minimum (counterclockwise).

2) Turn the head unit volume control to about 3/4 of its maximum volume.

3) Set the two L-R LEVELS towards maximum sensitivity until you get sporadic lighting of PEAK R-PEAK L leds with high dynamic musical passages.

**IMPORTANT:** if you should hear distortion phenomena without the PEAK L-R leds lighting up, it means that a distorted signal is coming from the head unit. In this case, turn the head unit volume down until there's no longer any distortion. Repeat calibration operation omitting step 2.

## **PROTECTIONS**

The device is provided with several electronic protections which protect the amplifier from dangerous or wrong functioning conditions, avoiding to interfere with the music signal in order to get the best performances in every condition.

- Outputs protection: any type of short circuit on the speaker wires, be it between themselves or to ground, will cause no damages.

- Temperature protection: anomalous use conditions or high ambient temperature (above 60°C), that doesn't allow the amplifier to discharge the produced heating (maximum working temperature of the device 80°C), causes the protection intervention.

- Protection against inverted polarity of the power supply: if the power supply cables polarities should be mistakenly inverted, the electronic circuitry will be protected by burning the external fuse, that will have to be replaced with an identical one.

- Protection against continuous current in the output.

- Protection against excessively low or dangerous loads.

A front red LED (SAFE) indicates intervention of protection circuits. Once the cause of malfunctioning is eliminated, you need to turn head unit off and turn it back on in order to have the device function again. The amplifier will function normally.

## **OUTPUTS CONNECTION**

**THREADED CONNECTORS (Speaker L-R).** Connect the speakers or the speakers passive crossover according to polarities.  
**IMPORTANT:** Never connect -R and -L outputs to ground or to each other. If a crossover filter is used, be sure the two channels don't have a common ground. An allen key is provided for the terminals screws.

## **MONO CONNECTION**

Position **MONO** push-button to **ON**. Use **INR** input. Take the power output from the +L (LEFT) and -R (RIGHT) terminal.  
It's possible to obtain **MONO** use just for **SUBWOOFER** frequencies and to have a **STEREO** system for high frequencies using the **TRIMODE** configuration (pict.1); in this case leave **MONO** push-button to **OFF** position and apply the connection system according to the picture. Refer to chart for inductance and capacity values relative to the desired crossover frequency.

## **POWER SUPPLY CONNECTION**

**THREADED CONNECTORS (Power) ±.** The battery positive is connected to the + **POWER** terminal inserting a fuse (provided) next to the battery itself.  
- **POWER** terminal must be connected to the battery negative (ground) through the car chassis, taking care to guarantee an excellent electrical contact on a metallic point not covered with paint or insulating materials of any kind.  
For the electrical connections described, use adequate cables, with a minimum diameter of 6 mm (3 A.W.G.). An allen key is provided for the terminal screws.

## **TURN ON CONTROL CONNECTION**

**THREADED CONNECTORS (Remote in-out).** Connect the amplifier **REMOTE IN** input to the proper head unit output (**REMOTE AUX**), or to electric antenna control. **REMOTE OUT** output is used to turn on another possible device. A green LED ON indicates when the amplifier is turned on.

## **MUTING CONTROL CONNECTION**

**THREADED CONNECTORS (Mute in-out).** **MUTE IN** input silences the amplifier. The device goes into muting when it receives a positive voltage between 3 VDC and 15 VDC, or when ground (**GND**) is applied.  
**MUTE IN** can be connected to the proper head unit output (if provided) or to the **MUTE** output of a cellular phone; in this case, when there is a phone call, the car system is silenced. When the conversation is over, the amplifier will automatically play again. The amplifier **MUTEOUT** contact must be connected to a second amplifier (if available) provided with a special **MUTE IN** output. In this way, the second amplifier becomes dependent on the first one as far as the car system **MUTE** functions are concerned.

Then there is a complementary voltage amplifier stage in **CASCODE** configuration and realised with **BJT** transistors.

These circuits have been duly polarised and configured as transconductance modulators (**HCP - HCN** Hyperlinear correction) with filter functions for transient distortions.

The electrical features of the **V-AMP 12LV** section are: **THD** distortion at 100 Vpp: 0.04%; **Sleaw Rate:** 250/μs; **Baudwidth:** DC÷1.5 MHz; **S/N:** ratio 122 dBa. **Monotonic** decreasing distortion spectrum with stop at the harmonic sixth.

The final stage driven by the above mentioned module is a complementary symmetric inverted triplet configuration and it is supplied with a driver and predriver at low **Cob** and four + four transistors amplifiers of 150 W, 15 A with Ft of 30 MHz.

The total reaction rate used in this amplifier is of 4 dB and the global performances obtained by the whole amplifier stage are: bandwidth 1.5 Hz÷180 KHz; **THD** distortion: min. 0.1 % at 160 W; **Slew Rate:** 90 V/μs.

## **POWER SUPPLY**

The switching power supply is composed by a **PWM** controlled push-pull double power supply. One of them generates and controls only positive voltages, the other one the negative voltages. The power supply system functioning logic is directed by a single circuit, called **PWM CONTROLLER**, which also attends to the **PWM** generation in the positive power supply and operates in a synchronic way with a second circuit called **PWM SERVEUR**, which has the task of making the **PWM** control of the negative power supply. Synchronism between the two **PWM** generator clocks avoids the formation of residual products at low frequency which could be converted into audio disturbance noises by the amplifier. The particular dynamic control of the audio amplifier voltages allows the voltage linear levelling and is able to supply energy instantaneously.

This control is active up to the frequency of about 800 Hz; the levelling at upper load frequencies is given to the transformer capacities which are equal to 15000 μF. The measurable result of such a complex controlling system is to have a "ripple" on the transformer voltage equal to 300 mV when the **HV sedici** is loaded at the maximum power on resistive load.

As it regards the sound, the fact that we have a perfectly stabilised power supply voltage for the final stage allows the correct reproduction of high dynamic content transient signals, it guarantees details, acoustic precision and very good reconstruction of sound image.

The power supply delivers three secondary voltages: the first one is for the final power stage at ±40 V, the second one for the internal preamplifier at ±25 V and the third one at ±47 V for the final stage driver circuit.

The power supplies are provided with a primary protection which interdicts their functioning in case of non operative overloading, avoiding circuit damages.

All interactions between power supply and amplifier (secondary voltages control, muting circuits control and reception of information about the final stage protection) are effected through optocoupler circuits.

This solution avoids the transfer of the noises coming from the car electric device to the car radio section.

## TECHNICAL FEATURES

POWER SUPPLY	11÷15 VDC
IDLING CURRENT	2.6 A
MAX CONSUMPTION	60 A
CONT. NOMINAL POWER (2 ch 4 Ohms)	150 + 150 W (RMS)
2 ch x 4 Ohms; 0.3 % THD; 12 VDC	160 + 160 W (RMS)
CONTINUOUS OUT POWER (2 ch 4 Ohms; 13.8 VDC)	320 + 320 W (RMS)
CONTINUOUS OUT POWER (2 ch 2 Ohms; 13.8 VDC)	500 + 500 W (RMS)
CONTINUOUS OUT POWER (2 ch 1 Ohm; 13.8 VDC)	640 W (RMS)
CONT. OUT POWER (1 ch 4 Ohms; 13.8 VDC) Bridge	1000 W (RMS)
CONT. OUT POWER (1 ch 2 Ohms; 13.8 VDC) Bridge	0.1 %
DISTORTION - THD	0.08 %
DISTORTION - IMD	1.5 Hz - 180 KHz
BANDWIDTH	100
DAMPING FACTOR (4 Ohms)	2.2 µS
RISE TIME	60 V/µS
SLEW RATE	102 dB
S/N RATIO	4 dB
TOTAL NEGATIVE FEEDBACK	3 ÷ 15 VDC
REMOTE IN	12 VDC - 150 mA
REMOTE OUT	GND / 3÷15 VDC
MUTE IN	12 VDC
MUTE OUT	0.2÷1.0 VRMS
PRE INPUT SENSITIVITY (unbalanced)	(±0.2 ÷ ±0.5 VRMS)
PRE INPUT SENSITIVITY (balanced)	1.0÷5.0 VRMS
AMP INPUT SENSITIVITY (unbalanced)	(±0.5 ÷ ±2.5 VRMS)
AMP INPUT SENSITIVITY (balanced)	10 KOhms
INPUT IMPEDANCE	8 - 4 - 2 - 1 Ohms
LOAD IMPEDANCE (stereo)	8 - 4 - 2 Ohms
LOAD IMPEDANCE (bridge)	256 x 60 x 406
SIZE BxHxL .mm	10.08 x 2.35 x 15.98
SIZE BxHxL .inch	

## PRECAUTIONS

- 1) In order for this device to function properly it's important that it is installed in a spot where the temperature is between 0°C (32°F) and 55°C (131°F)
- 2) It must be installed in a dry and well ventilated spot.
- 3) Power supply voltage is 12 VCC, negative to ground. Make sure that the characteristics of the vehicle electrical system are suitable.
- 4) For safe driving, it's advised to listen to music at a volume level that won't drown out external traffic noise.

## INSTALLATION

The **HV sedici** amplifier is characterized by its relatively compact size considering the performances it offers.

This makes installation possible even in the most unlikely places. For mounting use 6 self-threading screws provided.

**IMPORTANT:** The wooden moulding which protects controls on top of the device must be removed before installing. This is done by loosening the three screws through the 5mm allen key provided. Once the installation and calibration have been made, mount the wooden protective moulding. For excellent results it's advised to use **audison cable** products to complete your installation. They include: power cables, signal cables, speaker wires, signal connectors and all accessories needed to complete the wiring.

## INPUTS CONNECTIONS

**Pin ABS CONNECTORS (Inputs).** Observing polarity, connect L-R inputs to respective preamplified outputs of radio-cassette player, preamplifier or electronic crossover. In order to make **UNBALANCED** signal connections (traditional connection), it's possible to use pin RCA connectors used in almost all electronics on the market. In order to make **BALANCED** signal connections (taking the signal from a balancer-preamplifier outputs) it's necessary to use **ABS** signal connectors which you can find in **audison cable** catalogue. In case of unbalanced connection and in case the radio-cassette player doesn't share the signal GND (preamplified outputs) with the battery GND (chassis of the device itself), the shield of the shielded cable must be connected to the radio-cassette player chassis.

## BALANCED-UNBALANCED CONNECTION

**Balanced:** Position **BALANCED-UNBALANCED** push-button to **BALANCED**. For the amplifier inputs use the **ABS** connectors in Audison cable catalogue taking the preamplified signal from a device provided with balanced outputs.

**Unbalanced:** Position **BALANCED-UNBALANCED** push-button to **UNBALANCED**. In the **UNBALANCED** position device can be used in the unbalanced way (traditional way) and it's therefore possible to employ common Pin **RCA** signal connectors. For sensitivity values, refer to the technical features chart on the controls area of the device.

## CONNECTION TO EXTERNAL PREAMPLIFIER

Position the **PREAMP** push-button to **OFF** position (internal preamplifier exclusion). In this case the amplifier sensitivity decreases and it is necessary to connect the device inputs to an external preamplifier.

The sensitivity can be adjusted from a maximum of 1.0 VRMS to a minimum of 5.0 VRMS in unbalanced configuration (±0.5 VRMS to ±2.5 VRMS balanced).

With the **PREAMP** push-button to **ON** position (internal preamplifier on), the sensitivity changes from a maximum of 0.2 VRMS to a minimum of 1.0 VRMS in unbalanced configuration (±0.1 VRMS to ±0.5 VRMS balanced).

The chart on the controls area shows the different sensitivities according to the operative modalities of the amplifier.