

Audison measurement standards

(Power measures taken according to **audison** standard, 1998 edition)


- 12VDC and 13.8VDC;
- 1 kHz or crossover cut-off frequency;
- 0.3% THD @ nominal power; 1% THD @ continuous power;
- Tolerance: +10%; -5%;
- Continuous power given by RMS Voltage measured on resistive load;
- The nominal power of the amplifier is measured upon a battery voltage of 12 Volts with a 4 Ohm load and with all channels in function.

audison

OWNER'S MANUAL

CAR POWER AMPLIFIER

LR³⁰⁰₄



PRINTED IN ITALY - Code 10125770

audison

is a division of **elettromedia**

62018 Potenza Picena (MC) Italy

Tel. 0733.870870 • Fax 0733.870880 • <http://www.audison.com> • e-mail: com@audison.com

INTRODUCTION

INTRODUCTION

Audison thanks you for preferring this product and compliments you on your choice since it was designed in order to insure outstanding musical and instrumental performances.

Before use instructions, please carefully read the safety norms you have to respect in order to avoid unpleasant inconveniences and to enjoy this product at best.

PRECAUTIONS

- Avoid to install the amplifier where temperature is below 0°C or above 55°C and in non ventilated places.
- The amplifier needs 12VDC power supply voltage with negative to ground. Be sure that your car electric system is compatible with the amplifier ordinary functioning.
- For safer driving, we recommend to adjust volume not to drown external traffic sounds.

WARNING!:

While installing the amplifier, make sure that the cable coming from the battery positive pole (+) doesn't touch the amplifier heat sink.

The heat sink is directly connected to the battery negative pole (-) through the screws which fix it to the vehicle chassis. Its contact with the positive pole cable would cause short circuit and, thus, possible fires and battery damages.

Please connect power supply cables to the amplifier terminal blocks (POWER + and -) before and to battery AFTER, to get maximum safety.

CAUTIONS

INPUTS: If the source output signal ground (PRE OUT) is not connected to the source chassis and the system sound is not powerful enough or is distorted, try to solve the problem by connecting the output signal cable braided shield (PRE OUT) to a point of the source chassis.

OUTPUTS: Don't connect -L and -R power outputs to each other or to ground (car chassis). In case you use an external crossover, make sure that channels grounds are not connected one to the other.

audison cable PRODUCTS FOR ELECTRIC CONNECTIONS






audison cable





RECOMMENDED POWER SUPPLY CABLES

Cable must be chosen according to its length and to the system total power.


POWER SUPPLY TERMINAL BLOCKS		CABLES		BATTERY + AND GROUND	
					
4 Ohms	MAINCRIMP 10	For 10 A.W.G.	POWERFLOW 9 (red and black)	PR 52.17 R&B	RB 6.34.1G f = 6 (.24) RB 8.34.1G f = 8 (.31)
2 Ohms	MAINCRIMP 8	For 7 A.W.G.	POWERFLOW 7 (red and black)	PR 62.19 R&B	RB 6.45.1G f = 6 (.24) RB 8.45.1G f = 8 (.34)

RECOMMENDED SPEAKERS CABLES

SPEAKERS TERMINAL BLOCKS	CABLE	
		
MAINCRIMP 14	096/20	2 x 11 A.W.G.
MAINCRIMP 14	093/20	2 x 9 A.W.G.

RECOMMENDED SIGNAL CABLES

BEST series PIN-RCA / PIN-RCA extensions are available in the following sizes



BS 50 cm 50 (19.68 inch)	BS 300 cm 300 (118.11 inch)
BS 100 cm 100 (39.37 inch)	BS 400 cm 400 (157.48 inch)
BS 150 cm 150 (59.05 inch)	BS 450 cm 450 (177.16 inch)
BS 200 cm 200 (78.74 inch)	BS 500 cm 500 (196.85 inch)
	BS 600 cm 600 (236.22 inch)

Description	p. 4
In-Out panel	
Functions	5
Power supply panel	
Functions	6
Fuse replacement	7
Controls panel	
Functions and controls	8
Setting panel	
Functions	10
Amplifier configuration	10
Subsonic filter cut-off frequency modification	11
VCA-VCA1D modules insertion	11
Technical features	
Size for fixing	12
LRx 4.300	12
Accessories	
VCR01K, VCRAK and VCRDK	13
CLK2 - LRx Cooling Kit	14
Configurations	
Block diagram	16
Configurations table	17
Controls panel diagram and configuration switches	17
Configuration examples	
Front+Sub	18
Front+Rear+Sub	18
Front+Rear+Sub	19
Installation	
Logo rotation	20
Amplifier fixing	21
Electric connections	21
audison cable products for electric connections	22
audison measurement standards	24

DESCRIPTION

Audison LRx 4.300:

Four channel car power amplifier characterised by excellent musical performances, small size and outstanding energy reserve.

Its PWM power supply stage is made with two pairs of 70A MOSFETs; it is stabilised and oversized. Input stage is provided with a special circuit (LNS) which permits the system disturbances rejection, reducing noise that is usually due to the vehicle electric parts (alternator, electronic injection, etc.), without altering musical signal quality.

Driver stages are characterised by a very linear circuitry. They have coupled differential transistors and an A Class complementary voltage amplifier. Power sections have Darlington configuration with high gain and SOA (Safety Operation Area) BJT TO247. Thanks to its great capacity to supply current, this amplifier can easily drive even the hardest loads and satisfy whatever power needs. It can give 65W per channel on 4 Ohm load and 105W per channel at 2 Ohms in continuous mode. Power increases up to 210Wx2 at 4 Ohms in mono (bridged); it is 65Wx2 and 220Wx1 at 4 Ohms in three channel configuration (3-Ch). Differently from what occurs with other amplifiers, LRx 4.300 is not blocked by protection systems immediately below 2 Ohms. Its exclusive "Overload Limiter" circuit allows it to go on working, limiting output power and pointing out how hard the applied load is by the "Limit" LED blinking.

Its big power reserve, its constant control at low frequencies and its exquisite timbre qualities make it an ideal amplifier to realise systems designed to attain outstanding musical features and very high sound pressures (SPL).

LRx 4.300 has a bypass subsonic filter (24dB/Oct.) with adjustable frequency, pre-set at 20Hz. It also has a HI-PASS (12dB/Oct.) and a LO-PASS (12-24dB/Oct.) Butterworth crossover with independent frequencies; they can be bypassed through a switch under the setting panel, in the amplifier bottom. Another switch under the setting panel permits to configure the preamplified output (OUT) as additional input (IN B), in order to accept the source second output for Rear system.

In case LRx amplifiers are used in extremely difficult conditions (very low loads) or in installations where space is too narrow and their heat sink cooling is not enough, they can be employed together with CLK2 cooling system (optional). It is a system made of two units to apply onto the amplifier sides; each of them is provided with an electronically controlled fan that allows the amplifier thermal stabilisation (see "CLK2 – LRx Cooling Kit").

Protection includes:

- **RGP** (Resettable Ground Protection) circuit; in case a short circuit occurs between loudspeakers outputs and car chassis, it detects a high current flow in the pre-input ground and acts by putting the amplifier in stand-by, protecting its circuitry;
- a device against short circuits and against DC in the outputs, to protect loudspeakers;
- a device that detects the amplifier temperature excessive increase and stops its functioning until optimal conditions occur again.

Once the causes which implied protection circuits intervention have been checked and solved, the amplifier is reset by switching it off and on again.

The amplifier is also provided with another general protection which is insured by an internal strip fuse, very easy to reach.


Optional:

The following devices are available upon request:

- 1 – Three kits for subwoofer volume remote control:
- VCR01 and VCRAK (analogue and specific for subwoofer);
- VCRDK (digital; it can be used for master volume control or for level control of any ways in a multichannel system).
- 2 – CLK2 cooling system.


INSTALLATION

AMPLIFIER FIXING



Fix the amplifier through the self-tapping screws (4.2 x 16) given with it.

ELECTRIC CONNECTIONS



CAUTION!

For the system safer protection, we recommend the use of a strip fuse on the cable that connects the battery positive pole to the amplifier POWER (+) terminal block. This fuse has to be installed about 10 cm far from the battery; its value will have to be equal or slightly higher (+10% approx.) than consumption @13.8 VDC, according to the different configurations (see "Technical features").


It will have to be equal to the sum of the values of all fuses in case system consists of several amplifiers or in case amplifiers have several fuses.

LRx 4.300 FUSE: 30A

POWER SUPPLY CABLE SIZE
Length: 4/5 m



Load	4 Ohms		2 Ohms	
Unit of measure	mm ²	A.W.G.	mm ²	A.W.G.
LRx 4.300	4.5	10	9	7

LOGO ROTATION





1 - Remove the transparent cover which protects controls and then the 4 screws which block the metal plate by using multispanner.

2 - Remove the plate without damaging the silkscreen printed panel which will have to stay on. We suggest that you seize both plate grips with your hands and pull them by blocking the silkscreen printed panel with your fingers against the amplifier chassis at the same time. This will permit to remove the plate from the panel without damages.



3 - Remove the strip with audison logo.

4 - Put the strip back again after turning it, so that audison logo is upside down.




5 - Mount the plate back by fixing it through the screws; then, re-assemble the transparent cover which protects controls.

FUNCTIONS

1


CH A/HI-PASS, CH B/LO-PASS

Power outputs of the amplifier left and right channels. Connect the speakers cables to these outputs according to polarity. Terminal blocks accept cables up to 9 A.W.G. max (see "*audison cable* products for electronic connections" as far as their size is concerned). We recommend the use of *audison cable* products. Please use +L and -R terminal blocks called **mono** in order to connect every channels pair in bridge and exploit the maximum power insured by this configuration.



2

PPS (Phantom Power Supply)
Power supply socket for *audison* external audio accessories.



3

IN A

Left (L) and right (R) inputs of the amplifier A channels. The preamplified outputs (PRE OUT) of a source (head unit, CD player, DAT, etc.) or of an external electronic crossover must be connected to them. Connect only the right (R) channel input in order to use the amplifier in mono.

4

IN B/OUT

Left (L) and right (R) inputs of the amplifier B channels or amplifier HI/BYPASS preamplified outputs (see "Configurations table"). Connect only the right (R) channel input in order to use the amplifier in mono.

FUNCTIONS

1

REMOTE IN

Terminal to connect Remote cable, which comes from the source and which controls the amplifier switching on. Applied voltage must be between 7 and 15VDC.



2

REMOTE OUT

Terminal to repeat the switching on control (Remote IN) coming from the source. It is used to switch on another amplifier or device in the system simultaneously. Available voltage is the same as the one applied on Remote IN.

3

VCR (optional kit)

Terminals to connect VCR01/VCRA/VCRD adjuster included in VCR01K/VCRAK/VCRDK volume remote control kits.

4

FUSE (30A)

Strip fuse. It insures the amplifier general protection. In case the fuse breaks down, please replace it by respecting its original value.


CAUTION: If you want to protect the system even more, please put a strip fuse onto the cable which connects the battery positive pole to the amplifier POWER (+) terminal block (see "Electric connections").

5


POWER

Terminal blocks for the amplifier power supply cable connection. Connect positive and negative poles according to indicated polarities. Holes have 8mm diameter and accept cables up to 3 A.W.G. max. In order to get the best current transfer, please use power supply cables with as big a section as possible. **audison cable** catalogue offers you a complete range of such products which can satisfy whatever demands; you can also find **Maincrimp** terminals in it. We strongly recommend their use because they contain the cable non protected end and allow the terminal block to fasten all its useful section.


FRONT+REAR+SUB




FRONT+SUB




FRONT + REAR + SUB




FUSE REPLACEMENT




1 - Open the transparent cover by pushing the two teeth in its lowest corners to the direction indicated by the arrows.



2 - Remove the screws which fasten the fuse to eliminate pieces of the broken one; prevent them from going into the device.



3 - Check the value of the new fuse to assemble, then fix it by gradually and alternately fastening the two screws. This will avoid voltage drops along the line and will make the device perfect functioning easier.



4 - Close the transparent cover.

FUNCTIONS AND CONTROLS


1

LIMIT (orange LED)

It indicates the Overload Limiter circuit is on.

Caution:

When this led is on (although sporadically), it means the applied load is a hard one. The activation of Overload Limiter circuit (output power limiter) will anyway allow the amplifier to function without distortions. In case Overload Limiter gets on too frequently (at every power peak), you will need to check if there are any failures or a too hard load (that's to say impedance is about 50% lower than the minimum recommended one). The amplifier can go on functioning in these conditions but power will inevitably decrease.



2

ON (green LED)

It indicates the amplifier is on.

3

A CHANNELS (Level)

It adjusts the amplifier A channels input sensitivity and sets its output level.

CONFIGURATIONS TABLE

LRx 4.300 can be configured as follows:

Config. 1 = Front (Hi 12 dB) + **Sub:** (Lo 12/24 dB); IN A (1 IN) – Pre Out (Hi 12 dB)


Config. 2 = Front (Hi 12 dB) + **Sub:** (Lo 12/24 dB) ; IN A-B (2 IN) – Ch. B mono (Lo 12/24 dB)

Config. 3 = Ch. A (Full Range) + **Ch. B** (Full Range); IN A (1 IN); Pre Out (Full Range)


Config. 4 = Ch. A (Full Range) + **Ch. B** (Full Range); IN A+B (2 IN); Pre Out (Full Range)

CONFIG.	CH A-HI	CH B-LO	IN B/ PRE OUT	X-OVER	IN-SELECT
1			PRE OUT	<input type="checkbox"/> OFF <input checked="" type="checkbox"/> ON	<input type="checkbox"/> 1IN <input checked="" type="checkbox"/> 2IN
2			IN B	<input type="checkbox"/> OFF <input checked="" type="checkbox"/> ON	<input type="checkbox"/> 1IN <input checked="" type="checkbox"/> 2IN
3			PRE OUT	<input type="checkbox"/> OFF <input checked="" type="checkbox"/> ON	<input type="checkbox"/> 1IN <input checked="" type="checkbox"/> 2IN
4			IN B	<input type="checkbox"/> OFF <input checked="" type="checkbox"/> ON	<input type="checkbox"/> 1IN <input checked="" type="checkbox"/> 2IN

CONTROLS PANEL DIAGRAM AND CONFIGURATION SWITCHES



BLOCK DIAGRAM



4

B CHANNELS (Level)

It adjusts the amplifier B channels input sensitivity and sets its output level.

5

A CHANNELS (Stereo/Mono)

It permits to configure A channels outputs signal as stereo or mono.

6

B CHANNELS (Stereo/Mono)

It permits to configure B channels outputs signal as stereo or mono.

7

SUBSONIC

It permits to eliminate subsonic frequencies; these sounds cannot be heard by human ears but cause useless and damaging stress to amplifier and speakers. Subsonic filter can be bypassed (**BYPASS**) and it is pre-set at **20 Hz**. Its cut-off frequency can be adjusted between 16 and 32 Hz through 4 Hz steps; this occurs by replacing the special resistors located into a socket which can be reached through the setting panel in the amplifier bottom.

8

F1 SLOPE

It permits to choose LO-PASS filter slope between 12dB/Oct. (stereo) and 24dB/Oct. (mono, L+R).

9

F1

It permits to adjust LO-PASS filter cut-off frequency between 40 Hz and 5 kHz.

10

F2

It permits to adjust 12dB/Oct. HI-PASS filter cut-off frequency between 40 Hz and 5 kHz.

11


SAFETY (red LED)

It indicates that the amplifier protection circuits are on. In order for the amplifier to work again, you need to switch the system off and then on after 10 seconds at least. We recommend to check all connections before switching the amplifier on again.

If LED stays on, please contact Audison authorised after sale centres.

FUNCTIONS

It permits to reach the switches for the amplifier configuration, the resistors to set subsonic filter cut-off frequency and to insert VCA modules for the subwoofer volume remote control.




AMPLIFIER CONFIGURATION


LRx 4.300 configuration occurs through two switches, **IN SELECT** and **X-OVER**, located under the setting panel.

•**IN SELECT** switch (1 IN - 2 IN) permits to use the preamplified output (OUT) as additional input (IN B). In this case, you will be able to realise a Front + Sub system, where IN A input drives Front, while IN B input accepts the possible subwoofer output, to be filtered at 24dB through F1 Slope switch in the controls panel and to be adjusted through the head unit Fader. IN B input can also be used to make a full range, Front-Rear system, which will be driven by two full range signals by bypassing crossovers (X-OVER on OFF). These signals will have to be suitably filtered through external crossovers.



•**X-OVER** switch activates (ON) the two Lo-Pass and Hi-Pass filters, indicated by F1 and F2 respectively in the controls panel. When F1 and F2 crossovers are off (X-OVER on OFF), you have full range signals on the amplifier power outputs.




Installation:



CLK2 should be used when LRx amplifiers work in extremely hard conditions (very low loads) or in installations where space is too narrow and heat sink cooling is not enough. It consists of two units to apply onto the amplifier sides; each of them is provided with an electronically controlled fan. Its intervention depends on a thermal sensor that starts the system as soon as LRx heat sink reaches 45°C. The same sensor is connected to a special circuit which controls the two fans speed progressive increase when temperature increases, too.




Remark: Cut the new resistors rheophores according to the size in the picture.




Replace FS1, FS2, FS3, FS4 resistors according to the values in the setting panel table.

LRx 4.300 can accept one of the three optional kits which allow the subwoofer volume remote control: VCR01K, VCRAK or VCRDK.
These kits have a specific module, VCA or VCA1D, to insert into the amplifier through the setting panel.

REMARK: Sub volume remote control function is on only when X-OVER switch, in the setting panel, is ON.



1 - Remove BYP12 bridge.



2 - Insert VCA/VCA1D module.

⚠ - Insertion key. It prevents the module from being inserted in the wrong way.

